



모델명 : DTD147

도번	부품코드	품명	단위
001	187388-6	HOUSING SET	PC.
002	897166-3	BTD147 NAME PLATE	PC.
003	266130-9	TAPPING SCREW BIND	EA
004	419041-9	F/R CHANGE LEVER	PC
005	141448-8	SWITCH COMPLETE	PC.
006	619297-6	ROTER	PC.
006A	619353-2	ROTOR	PC.
007	632A40-2	STATOR UNIT	PC.
008	620136-5	LED CIRCUIT	PC.
009	643860-3	TERMINAL	PC.
010	231951-8	RING SPRING 11	PC
011	267085-1	FLAT WASHER 12	PC
012	233005-7	COMPRESSION SPRING 13	PC
013	326072-0	BIT SLEEVE	PC.
014	424495-7	BUMPER	PC.
015	453664-3	HAMMER CASE COVER	PC.
016	141477-1	HAMMER CASE COMPLETE	PC.
017	261151-6	NYLON WASHER 19	EA
018	216001-0	STEEL BAL 3.5	EA
019	326070-4	ANVIL N	PC.
020	326054-2	HAMMER	EA
021	216001-0	STEEL BAL 3.5	EA
022	267175-0	FLAT WASHER 24	PC
023	234251-5	COMPRESSION SPRING 25	PC.
024	346466-3	PLATE	EA
025	216011-7	STEEL BALL 5.6	EA
026	227233-4	SPUR GEAR 22	PC.
027	326066-5	SPINDLE	EA
028	256253-1	PIN 5	PC
029	253362-7	THIN WASHER 12	EA
030	227150-8	INTERNAL GEAR 51	PC
031	211140-1	BALL BEARING 6901LLB	PC
032	213507-9	O RING 40	PC
033	158145-9	BEARING BOX COMPLETE	PC.
035	187388-6	HOUSING SET	PC.
036	141583-2	SWITCH PLATE COMPLETE	PC.
037	453665-1	BUFFLE PLATE	PC.
A01	346317-0	HOOK	PC.
A02	266622-8	+ TRUSS HEAD SCREW M4X12	PC.