


모델번호 PJ7000 PLATE JOINER



모델명 : PJ7000

도번	부품코드	품명	단위
001	922422-3	HEX. SOCKET HEAD BOLT M8X16	EA
002	941202-8	FLAT WASHER 8	PC
003	453218-6	GRIP	PC.
004	266324-6	TAPPING SCREW 4X22	EA
005	417771-6	PIN CAP	PC
006	234057-1	COMPRESSION SPRING 8	EA
007	252186-8	HEX. NUT M6	PC.
008	227545-5	SPIRAL BEVEL GEAR 10	PC
009	213445-5	O-RING 26	PC
010	211092-6	BALL BEARING 629X50LLU	EA
011	962105-3	RETAINING RING R-26	EA
012	413126-3	GUIDE PLATE	PC
013-1	240139-9	FAN 56	PC.
014	517648-6	ARMATURE ASSY 220V(INC. 4.5.7)	PC
015	681636-0	INSULATION WASHER	PC
016	210034-7	BALL BEARING 607LLB	PC.
017	421868-5	LABYRINTH RUBBER RING 19	PC.
018	450796-7	BAFFLE PLATE	PC
019	266325-4	TAPPING SCREW 4X70	PC.
020A	635113-4	FIELD ASSY 220V	PC.
021	896483-8	PJ7000 NAME PLATE	PC.
022	266492-5	TAPPING SCREW 3X8	PC.
023	643839-4	BRUSH HOLDER 6X9	EA
024	195026-6	CARBON BRUSH CB-459	PC.
025	650621-4	SWITCH PS10	EA
026	687681-3	STRAIN RELIEF	EA
027	266326-2	TAPPING SCREW 4X18	PC
028	645200-1	NOISE SUPPRESSOR	PC
029	682569-2	CORD GUARD	PC
030	696414-5	POWER SUPPLY CORD 1.0-2-2.5	EA
031	266326-2	TAPPING SCREW 4X18	PC
032	450794-1	REAR COVER	PC
033	450797-5	SWITCH LEVER	PC
034	233121-5	COMPRESSION SPRING 4	PC.
035	450795-9	MOTOR HOUSING	EA
036	419566-3	SWITCH KNOB	PC
037	213032-0	O RING 4	EA
038	256510-7	SHOULDER PIN 4	PC
039	141327-0	GEAR HOUSING COMPLETE	PC.
039-1	263002-9	RUBBER PIN 4	EA
040	210033-9	BALL BEARING 696ZZ	PC.
041	233950-6	RING SPRING	EA
042	227546-3	SPIRAL BEVEL GEAR 37	PC
043	962151-6	RETAINING RING R-32	EA
044	211129-9	BALL BEARING 6201LLU(DDW)	EA
045	326120-5	SPINDLE	PC.
046	213561-3	O RING 42	PC
47	318811-2	BEARING BOX	PC.
48	911136-9	PAN HEAD SCREW M4X20	EA
49	911136-9	PAN HEAD SCREW M4X20	EA
50	931203-4	HEX. NUT M5	PC
51	266741-0	PAN HEAD SCREW M5X50	PC.
52	453406-5	BASE COVER	PC.
53	326145-9	ROD 10	PC.
54	141247-8	FENCE COMPLETE	PC.
55	961017-7	STOP RING E-3	EA

모델명 : PJ7000

도번	부품코드	품명	단위
56	256689-4	PIN 4	PC
57	318813-8	BASE	PC.
58	231282-5	COMPRESSION SPRING 2.4	EA
59	216001-0	STEEL BALL 3.5	EA
60	318814-6	STOPPER	PC.
61	266264-8	HEX. SOCKET HEAD SCREW M5X6	EA
62	266738-9	(+)PAN HEAD SCREW #REF!	PC.
63	213008-7	O RING 22.4	EA
64	415252-4	DUST NOZZLE	PC
65	265785-7	THUMB SCREW M5X10	PC.
66	232131-9	LEAF SPRING	EA
67	213023-1	O RING 4	PC
68	266737-1	FLAT HEAD SQ. NECK BOLT M6X20	PC.
69	231282-5	COMPRESSION SPRING 2.4	EA
70	216001-0	STEEL BALL 3.5	EA
71	231795-6	TENSION SPRING 8	EA
72	272263-0	LEVER 40	PC.
73	252159-1	HEX NUT M6	EA
74	961014-3	STOP RING E-8	PC
75	253804-1	FLAT WASHER 6 FOR HR4000C	EA
76	224280-6	INNER FLANGE 40	PC
77	224505-8	LOCK NUT 10-40	EA
78	318845-5	BLADE COVER	PC.
79	424479-5	RUBBER SPIKE	PC.
80	213023-1	O RING 4	PC
A01	123149-0	ANGLE GUIDE ASSEMBLY	PC.
A02	123150-5	Dust bag For PJ7000,DPJ180	EA
A03	415579-2	SET PLATE 4	PC
A04	B-20644	CUTTER 100MMX6T	EA
A05	782401-1	LOCK NUT WRENCH 20	EA